

Operating Instructions



Unlocking you tub

After a period of time the hot tub control panel will automatically lock to prevent accidental access. The panel can also be locking by pressing the "LOCK" button. A padlock symbol will appear on the display when the panel is locked.

To unlock your tub firstly make sure there are no numbers showing underneath the time display, if there are press a button until it disappears, then press:

1. "AUDIO/CD"
2. "MHZ/ON"
3. "+/SET"
4. "PUMP3"
5. "PUMP2"
6. "PUMP1"

And the unlock symbol will disappear.

Setting the Clock

Press "ON/OFF" so that "--" is displayed

Press "+/SET"

Press "MIN" to set the minutes

Press "HOUR" to set the hour.

After a short period the clock will stop flashing and the time is set.

Radio/CD

To use the radio press the "AUDIO/CD" button, for the auxiliary input press the "AUDIO/CD" button again and

To tune the radio press the "TUNE" button, the "+" and "-" buttons to adjust the frequency

Setting the Heat

To turn on and set the heating of your tub, press the "HEAT" button, a heating symbol will appear and pump 3 will turn on to start heating. To adjust the heat press the "..." button to raise the temperature and the "...," button to lower the temperature. When temperature is reached then the pump will automatically turn off. NOTE: If "PUMP3" button is pressed whilst the heater is on then when temperature is reached then pump will continue running.

Setting Auto Run Sequence

1. Turn hot tub control panel off using on/off key (three small bars appear under clock when off)
2. Press "PUMP3" button
3. Press "MHZ/ON" button (a new clock dialog should start to flash/blink)
4. Set desired time to come on using 'hour' and 'minute buttons'
5. Press "+/SET" button and use "HOUR/..." key to set desired duration between 1 -5 minutes
6. Press "+/SET" button again and ozone symbol flashes, press ozone button to turn ozone on or off during auto run.
7. Press "+/SET" button again to take you back to original 'time on clock'.
8. Wait approx 5 blinks of clock and display will return to current time and a circular cymbal will be displayed.
9. Turn hot tub control panel back on using on/off key three small bars disappear.

To disable auto run...

As above to step 2 but instead of pressing 'MHZ/ON' button press 'TUNE/OFF' button. Circular symbol disappears

