

MSPA-MP-CE SPA PACK

• Gecko Electronics Inc. •



The **Quick Reference Card** provides a quick overview of your spa's main functions and the operations accessible with your digital control pad. Note that some functions require the use of the TSC-4 keypad (10 keys). *

Starting Pump 1:

Press **Pump 1** to turn Pump 1 on at low speed. Press a second time to turn Pump 1 to high speed. A third time turns Pump 1 off. A built-in timer automatically turns pump off after 20 minutes, unless it has been manually deactivated.

▼ The "Pump 1" indicator lights up when Pump 1 is on at high speed. It flashes when Pump 1 is on at low speed.

Starting Pump 2:

Dual-speed pump system: Press **Pump 2** to turn Pump 2 on at low speed. Press a second time to turn pump to high speed. A third time turns pump off.

Single-speed pump system: Press **Pump 2** to turn Pump 2 on. Press a second time to turn Pump 2 off.

In both cases, a built-in timer turns Pump 2 off after 20 minutes, unless it has been manually deactivated.

▼ The "Pump 2" indicator lights up when Pump 2 is on. With a dual-speed pump, it will flash when Pump 2 is on at low speed.

Starting Pump 3: *

Press **Pump 3/Off** to turn Pump 3 on. Press a second time to turn Pump 3 off. A built-in timer automatically turns pump off after 20 minutes, unless it has been manually deactivated.

Starting the blower:

Press **Blower** to turn blower on at high speed. Press a second time to turn blower to low speed. A third time turns blower off. A built-in timer automatically turns blower off after 20 minutes, unless manually deactivated first.

▼ The "Blower" indicator lights up when blower is on at high speed. It flashes when blower is on at low speed.

Turning the light on:

Two-intensity spa light: Press **Light** key to turn light on at high intensity. Press a second time to turn light to low intensity. A third time turns light off.

One-intensity spa light: Press **Light** key to turn light on. Press a second time to turn light off.

In both cases, a built-in timer turns light off after 2 hours, unless manually deactivated first.

▼ The "Light" indicator is displayed when light is on at high intensity. It flashes when light is on at low intensity.

Fiber Box Option: If your spa has an optional fiber box, press **Light** key to turn fiber box (motor & light) on. Press a second time to turn fiber box motor off and leave light on. A third time turns both motor and light off. A built-in timer turns fiber box off after 2 hours, unless it has been manually deactivated. The "Light" indicator is displayed when fiber box light is on. It flashes when fiber box motor and light are on at the same time.

Setting water temperature:

Use **Up** or **Down** arrow key to regulate water temperature. The temperature setting will be displayed for 5 seconds to confirm your new selection.

ⓘ The "Set Point" symbol indicates the desired temperature, NOT the current water temperature!

Water temperature can be adjusted by 1° increments from 15 to 40° C (59 to 104° F).

Automatic water heater start:

When water temperature is 0.5° C (1° F) lower than the Set Point, the heater will automatically turn on until water temperature reaches Set Point plus 0.5° C (1° F).

▼ The "Heater" indicator lights up when the heater is on. It flashes when there is a request for more heat but the heater has not yet started.

Note: If your system is configured in Low Current mode, the heater will not start if two pumps or more are running at high speed.

Troubleshooting



"FLO" error message is displayed.

The system detects no water pressure while the pumps are running.

Check and open water valves. Check water level. Clean filter. Call your dealer or service supplier if problem persists.



"HL" error message is displayed.

The system has shut the heater down because the water temperature at the heater has reached 48° C (119° F).

The system has shut down because the water temperature in the spa has reached 44° C (112° F). Only the **Smart Winter Mode** will remain active.



"Prr" error message is displayed.

A problem has been detected with the temperature probe. Call your dealer or service supplier.

"FLC" error message is displayed.

A problem has been detected with the pressure switch. Call your dealer or service supplier.

The display is flashing.

A power failure has occurred. Press any key to reset the system, then reprogram all desired parameters.

"Prr" error message is displayed.

"FLC" error message is displayed.

Quick Reference Card





TSC-4 keypad is mandatory when some options are selected. *

Off mode *

Press and hold **Pump 3/Off** key for 5 seconds to turn the system down (i.e. to set it to Off mode) for 30 minutes. The "OFF" message is displayed. All keys are then disabled, unless you press **Pump 3/Off** to reactivate the system before the expiration of the 30-minute delay.

Temperature unit

Press and hold **Light** key for 5 seconds to toggle between °C and °F.

Inverted display

Press and hold **Filter** key for 5 seconds to invert the display. If a power-up occurs, the display always returns to default mode.

Filter cycles

The system automatically performs 2 filter cycles per day, at 12-hour intervals. During a filter cycle, Pumps 2 & 3 and blower run for one minute. Pump 1 then runs at low speed for the remaining of the cycle and "Filter Cycle" icon lights up. (If system is equipped with a circulation pump, all pumps and blower run for one minute. Circulation pump then runs for the remaining of the cycle and "Filter Cycle" icon lights up.)

Setting filter cycles:

- 1- Press **Filter** key.
- 2- The display will show **F xx**, with "xx" representing the duration in hours.
- 3- Use **Up** and **Down** arrows to change setting.
- 4- Press **Filter** key again.
- 5- The display will show **Fd xx**, with "xx" representing the delay before cycle starts.
- 6- Use **Up** and **Down** arrows to change setting.
- 7- Press **Filter** key to store settings.

40-minute filter cycle time-out: If you turn a pump, blower or light on during a filter cycle, the cycle will be interrupted and will only resume 40 minutes after the system has turned the last active output off.

Purge cycles

The system can perform a number of purge cycles per day. During a purge cycle, pumps and blower run for two minutes and "Filter Cycle" icon lights up.

Setting purge cycles:

- 1- Press **Filter** key.
- 2- The display will show **P xx**, with "xx" representing the currently set number of daily purge cycles.
- 3- Use **Up** and **Down** arrows to change setting.
- 4- Press **Filter** key to store settings.

Boost filtration mode

This function allows you to speed up filtration after intensive use of your spa or to mix chemicals. Simply keep **Pump 1** key pressed down for 5 seconds. Pump 1 will run at high speed for 45 minutes and "BOO" message will be displayed. Ozonator is also activated.

Water level sensor

If the system is equipped with an optional water level sensor and the sensor detects an insufficient level of water in the tub, the system will prevent pumps from starting and will display the "H2O" message. Pumps will be allowed to turn back on when water level returns above sensor.

Digital control pad lockout

This function allows you to prevent unauthorized parameter setting of the unit. This feature is especially helpful when young children have access to the keypad.

There are two modes you can choose from: *Full lock* or *Partial lock*. *Full lock* means that all keypad functions are locked. *Partial lock* means that the basic functions of the spa will remain accessible (pumps, blower and light), but it will be impossible to change the temperature Set Point, to override the Economy mode or to enter the Programming mode.

When control pad is locked, the "Lock" icon will be displayed.

Locking your digital control pad:

- 1- Press and hold **Econo** key for 5 seconds.
- 2- The display will show **LocP**, with "P" representing *Partial lock*.
- 3- Release key and keypad will be in *Partial lock* mode. Keep key pressed down for 5 more seconds if you want to be in *Full lock* mode. The "LocF" message will then be displayed.

When control pad is locked, all automatic functions of the system run as usual. If a key is pressed down, a "LocP" or "LocF" message will be displayed for 1 second. To unlock the keypad, simply press and hold **Econo** key again for 5 seconds.

Economy mode

To save energy, the Economy mode Set Point is 11 °C (20 °F) below the Normal mode Set Point.

➡ The "Economy Mode" icon lights up when Economy mode is on.

Setting Economy mode:

- 1- Press **Econo** key.
- 2- The display will show **E xx**, with "xx" representing the Economy mode duration.
- 3- Use **Up** or **Down** key to change setting.
- 4- Press **Econo** key again.
- 5- The display will show **Ed xx**, with "xx" representing the delay before mode starts.
- 6- Use **Up** and **Down** arrows to change setting.
- 7- Press **Econo** key a third time to store settings.

40-minute Economy mode time-out: If you turn a pump, blower or light on while Economy mode is on, the Economy mode will be interrupted and will only resume 40 minutes after the system has turned the last active output off. The "Econ" message or "Economy Mode" icon will flash, depending on your system configuration.

"CLE" message

Every two weeks, the "CLE" message might be displayed indicating to clean the filter (depending on your spa configuration). Press any key to reset the message.

Real-time clock *

Use **Clock** key to set real-time clock. The display toggles every 5 seconds alternately showing the hourly time and the current water temperature.

Summary of control panel parameters

- F xx** Filter cycle duration
- Fd xx** Filter cycle delay
- LocX** Control pad lockout
- E xx** Economy mode duration
- Ed xx** Economy mode delay
- P xx** Purge cycles

